

ERA

Maxim Window Handle Fitting Instructions

Installing a Maxim Window Handle (for PVCu Casement Windows)

To fit a Window Handle you will require the following tools:

- Screwdriver
- Hacksaw

Caution: This handle is supplied with a 40mm spindle which will need to be cut to size. Please check that the dimension between the screw holes (diagram A) mirror your current handle to ensure a correct fit.

Before you begin

The handle has been pre-fitted with a 40mm long spindle (diagram A). Measure the length of the existing spindle on the current handle, then cut this spindle to the required length.

A (See Diagram B) You will require a screwdriver. Place the handle in position and insert the spindle into the drive mechanism; insert fixing screw into top screw hole.

Open handle 90° to reveal bottom screw hole and insert screw, take care not to over tighten the screws. Push screw cover into the top screw hole and close the handle to re-engage locking mechanism.

Check operation.

Additional Information

Please note: This handle is only suitable for window locks operated by a handle with a spindle.

Maintenance - Handles should be cleaned with a soft dry cloth. If further cleaning is required we recommend a mild solution of warm, soapy water on a soft cloth. Dry thoroughly afterwards.

