

Retouch Crayons

- For filling and masking superficial scratches on finished wood
- Expand and contract with the wood
- Do not shrink or drop out
- Wide range of colours available



Product use

Liberon Retouch Crayons can be used to fill scratches, nail holes, worm holes etc. in furniture and other woodwork. Easy to use, they are available in a wide range of colours.

Application

Rub the crayon across the scratch until it is filled, allow to harden then buff off the excess with a cotton cloth. Retouch crayons may be blended together to create different shades.

Important: always test products on a spare surface or inconspicuous area for colour, compatibility and end result.

Packaging

Retouch Crayons are available in pine, mahogany, oak, walnut and mixed.

Colours

Mahogany, Pine, Oak, Mixed, Kitchen and Walnut.

Health & Safety

Keep out of the reach of children. Do not empty into drains.

This product should be used in accordance with the manufacturer's instructions. Recommendations are for guidance only since conditions of use are completely beyond our control. For technical or practical information on this or other Liberon products please contact Liberon Technical Services on 01797 367555

Liberon Limited, Mountfield Industrial Estate, New Romney, Kent TN28 8XU.

Tel: 01797 367555 Fax: 01797 367575 www.liberon.co.uk

Liberon Ltd is a V33 Group Company.