

Gloss Surface Cleaner



Key Features:

Gloss Surface Cleaner is a ready to use foam cleaner which quickly provides a smear free finish on gloss surfaces.

In just one quick and easy application it polishes leaving gloss kitchen cupboards, appliances, glass, mirrors or chrome surfaces free from grubby finger prints, water marks, dust and light dirt and looking as good as new.

Unika's Gloss Cleaner is the only product of its kind that restores a high sheen after every application. Other traditional multi-surface cleaners can be mildly abrasive causing gloss cupboards, for example, to become dull over time.

Gloss Surface Cleaner is a professional grade cleaner which also reduces the rate of static pick-up on any surface – reducing the build up of dust.

Directions for Use:

Spray sparingly onto gloss surfaces and buff dry with a micro fibre cloth.

For stubborn areas leave for 1 – 2 minutes for foam to collapse and the moisture to soften the marks.

Consumer Benefits:

Quick and easy to use. Gloss Surface Cleaner has been specifically designed to give the best cleaning to remove dust, light dirt and water marks from Gloss Cupboards.

Retailer Opportunity:

Can be sold alongside all Gloss kitchen sales as an Aftercare kit.

The customer will not find a specific cleaner like this in the supermarket. They will only find a multi surface cleaner which may be too abrasive for gloss surfaces.

UNIKA COLOR PRODUCTS LTD

Unika House, New York Way, New York Industrial Park,
Newcastle upon Tyne, U.K. NE27 0QF

Telephone: +44 (0) 191 259 0033

Fax: +44 (0) 191 257 4525

Email: sales@unika.co.uk www.unika.co.uk



The mark of responsible forestry



PEFC/16-33-1158



ISO 14001 001



OHSAS 18001 001



ISO 9001 001